



| Machine | Explode | Code | Description |
|--|---------|---|------------------------------|
| L715 - Buffalo Black Soup Kettle - 10Ltr | 1 | AC144 | S/S Lid |
| L715 - Buffalo Black Soup Kettle - 10Ltr | 2 | N289 | S/S Inner Pot |
| L715 - Buffalo Black Soup Kettle - 10Ltr | 3 | AT193 | S/S Top Collar |
| L715 - Buffalo Black Soup Kettle - 10Ltr | 4 |  | S/S Cross |
| L715 - Buffalo Black Soup Kettle - 10Ltr | 5 | AP552 | Internal Aluminium Container |
| L715 - Buffalo Black Soup Kettle - 10Ltr | 6 | AM182 | Thermostat |
| L715 - Buffalo Black Soup Kettle - 10Ltr | 7 | AL990 | Heating Element |
| L715 - Buffalo Black Soup Kettle - 10Ltr | 8 | AL991 | Spring |
| L715 - Buffalo Black Soup Kettle - 10Ltr | 9 |  | S/S Painted Exterior |
| L715 - Buffalo Black Soup Kettle - 10Ltr | 10 | N293 | Menu Label |
| L715 - Buffalo Black Soup Kettle - 10Ltr | 11 | AN461 | UK Power Cord |
| L715 - Buffalo Black Soup Kettle - 10Ltr | 11 |  | EU Power Cord |
| L715 - Buffalo Black Soup Kettle - 10Ltr | 12 | AN649 | Plastic Strain Relief |
| L715 - Buffalo Black Soup Kettle - 10Ltr | 13 | AP196 | Red Indicator Light |
| L715 - Buffalo Black Soup Kettle - 10Ltr | 13 | AL392 | Green Indicator Light |
| L715 - Buffalo Black Soup Kettle - 10Ltr | 15 | AD618 | EGO Switch |
| L715 - Buffalo Black Soup Kettle - 10Ltr | 16 | N111 | Plastic Leg |
| L715 - Buffalo Black Soup Kettle - 10Ltr | 17 | AD619 | Knob |
| L715 - Buffalo Black Soup Kettle - 10Ltr | 18 |  | The Bottom Cover With Screws |