




Machine	Explode	Code	Description
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	1-4		Mental Door
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	5		Plastic Door
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	6		Door Hook
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	7		Door Hook Spring
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	8-10		Mixer
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	11	AL206	Turntable Motor
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	12-13+42+44+51+26+28		Cavity Assembly
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	14	AL207	Interlocking Support
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	23		Microswitch No
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	24		Linkage Block
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	25		Microswitch Nc
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	15		Lower Hinge Assy
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	16	AL208	Base Plate
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	17	AL209	Oven Feet
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	18		Oven Bolt
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	19	AL210	High Voltage Transformer
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	20		Heat Insulation Plate
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	21		High Voltage Holder
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	22	AL211	High Voltage Capacitor
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	27+29		Waveguide Cover Assy
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	30		Magnetron Support
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	31	AL212	Thermostat
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	32	AL213	Magnetron
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	33		Magnetron Strip
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	34	AL214	Fan Blade
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	36		Fan Motor
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	35		Fan Cover
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	37		Limit Wire Clamp
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	38		Main Wire Harness
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	39		Outer Cover
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	40+50		Heat Shield
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	41		Power Cord Assembly
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	43	AL215	Noise Filter Board
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	45	AL216	Lamp With Support
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	46		Quartz Tube Shield
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	47		Lamp Cover
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	48	AL217	Thermostat
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	49		Reflexion Cover
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	52	AL218	Heating Element
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	58	AL219	Grill Rack
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	59		Plastic Door

DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	60		Door Glass
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	61		Door Handel Support
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	62	AL220	Door Handel
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	63	AL221	Membrane Switch
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	64		Control Panel Box
DJ610 - Nisbets Essentials Microwave - 21Ltr 750watt	65	AL222	Control Board Assy