




Machine	Explode	Code	Description
DR063 - Rowlett Esprit 2 Slot Toaster Jet Black	1		Espr-2 Body
DR063 - Rowlett Esprit 2 Slot Toaster Jet Black	2		Front Panel-2
DR063 - Rowlett Esprit 2 Slot Toaster Jet Black	3		Inner Assy-2
DR063 - Rowlett Esprit 2 Slot Toaster Jet Black	4		Heat Shield Assy-2
DR063 - Rowlett Esprit 2 Slot Toaster Jet Black	5		Finger Bar-2
DR063 - Rowlett Esprit 2 Slot Toaster Jet Black	6		Back Panel-2
DR063 - Rowlett Esprit 2 Slot Toaster Jet Black	7		Fixed Plate-2
DR063 - Rowlett Esprit 2 Slot Toaster Jet Black	8	AK221	Power Cord
DR063 - Rowlett Esprit 2 Slot Toaster Jet Black	9		Power Cord Buckle
DR063 - Rowlett Esprit 2 Slot Toaster Jet Black	10		Wire Bushing
DR063 - Rowlett Esprit 2 Slot Toaster Jet Black	11	AK222	Fuse Holder
DR063 - Rowlett Esprit 2 Slot Toaster Jet Black	12		Fuse
DR063 - Rowlett Esprit 2 Slot Toaster Jet Black	13	AK223	Thermostat Cut Out
DR063 - Rowlett Esprit 2 Slot Toaster Jet Black	14	AK225	Indicator
DR063 - Rowlett Esprit 2 Slot Toaster Jet Black	15	AK227	Timer-old version
DR063 - Rowlett Esprit 2 Slot Toaster Jet Black	16	AK228	Timer Knob-old version
DR063 - Rowlett Esprit 2 Slot Toaster Jet Black	15	AK239	Timer-From DR063-03
DR063 - Rowlett Esprit 2 Slot Toaster Jet Black	16	AK240	Timer Knob-From DR063-03
DR063 - Rowlett Esprit 2 Slot Toaster Jet Black	17		Base Plate
DR063 - Rowlett Esprit 2 Slot Toaster Jet Black	18	AK235	Crumb Tray
DR063 - Rowlett Esprit 2 Slot Toaster Jet Black	19		Screw/Nut
DR063 - Rowlett Esprit 2 Slot Toaster Jet Black	20	AK241	Rubber Feet (set 4)
DR063 - Rowlett Esprit 2 Slot Toaster Jet Black	21	AK230	Nut
DR063 - Rowlett Esprit 2 Slot Toaster Jet Black	22		Spring
DR063 - Rowlett Esprit 2 Slot Toaster Jet Black	23		Ejectorbar
DR063 - Rowlett Esprit 2 Slot Toaster Jet Black	24		Sphere Knob
DR063 - Rowlett Esprit 2 Slot Toaster Jet Black	25		Guard Wire
DR063 - Rowlett Esprit 2 Slot Toaster Jet Black	26	AK231	End Element 310W
DR063 - Rowlett Esprit 2 Slot Toaster Jet Black	27	AK232	Middle Element 400W
DR063 - Rowlett Esprit 2 Slot Toaster Jet Black	28	AK233	Element Link
DR063 - Rowlett Esprit 2 Slot Toaster Jet Black	29		Casting Jet Black for DR063
DR063 - Rowlett Esprit 2 Slot Toaster Jet Black	30		Casting Jet Black for DR063
DR063 - Rowlett Esprit 2 Slot Toaster Jet Black	32	AL132	3 Position Selector-From DR063-03
DR063 - Rowlett Esprit 2 Slot Toaster Jet Black	33	AL133	Selector Knob-From DR063-03