


## PART DESCRIPTIONS



## IMPORTANT SAFEGUARDS

- Check whether the voltage corresponds with that of the kettle.
- Only connect the kettle to a ground electric socket.
- Since the kettle is completely detachable and rotates a full 360 degrees on its circular base it's designed for both left-handed and right-handed people.
- The kettle is complete with indicator light, ON button, and safe lid locking system.
- You may open the lid by pressing the top button. The kettle has the following safety features: steam cut-off, boil-dry protection and overheat protection.

## NOTE

**The kettle should be used exclusively for boiling water. Do not use with other liquids or ingredients.**

## USING THE KETTLE

- To clean the kettle before first use: Boil a full kettle of water, then discard that water.
- Do not fill the kettle over the maximum marker.
- If insufficient water is used, the kettle may switch off.
- With too much water it may boil over.
- Always remove the kettle when filling it, to avoid water dripping onto the base.
- Turn it on by pressing the ON button of the handle. The indicator lamp will illuminate.
- Once the water boils, the kettle's power will automatically cut off.
- Then you may remove the kettle from its base and serve.
- Do not lift the kettle while operating.

- Do not operate the kettle when it is empty.
- If the appliance is accidentally turned on when empty, the boil-dry protection will automatically turn it off.
- Lift the kettle from its base and adding water to cool the boil-dry protection mechanism, enabling you to use the kettle normally again.

## NOTES

- **Do not remove the kettle from its base until it has turned off automatically.**
- **Filling the kettle over the MAX level may cause it to boil over.**
- **The kettle may only be used on its accompanying base.**
- **The cord should be completely unrolled from inside the base.**

## CLEANING

- Always unplug the kettle and let it cool down completely before cleaning.
- The outside of the kettle may be wiped down with a damp cloth.
- The base should always be cleaned without water.
- Don't dip the kettle into water or another liquid.

## WHEN REMOVING CALCIUM OXIDE

- Use an agent suitable for household appliances, such as for percolators.
- Do not turn the kettle on during this process.
- Allow the agent to soak in while the kettle is cool.
- Rinse the kettle several times afterwards with clean water.

## SAFETY TIPS

- Always place the kettle on a sturdy, stable surface.
- Do not operate the kettle unless the heating unit inside is filled with water.
- Never fill the kettle with anything but clean water.
- If the kettle is filled over the MAX indicator, it may boil over.
- The exterior of the kettle can become very hot. Only pick the kettle up by its handle.
- Ensure the kettle is not placed close to the edge of a table, counter top, etc. so it may fall.
- Always ensure the cord is not hanging over the edge of a table or a counter top so someone may trip over it.
- Do not use the kettle if the unit has been damaged in any way. Stop using it immediately.
- Do not try to repair the kettle or its cord yourself. That must be done by a trained professional.
- Do not place the kettle close to any source of heat.
- Always unplug the appliance before cleaning it or if it's suspected of being damaged in any way.
- The kettle must not be used by children without adult supervision.